PUROAIR

Aurora — UV Air Fan



AU-2L-S

Professional High-Performance UV-C Air Purifier

KEY FEATURES

- · Designed to provide continuous high guality UV air disinfection
- · Wall-mounted or mobile versions
- 18,000 hour ozone-free pure quartz 254nm UV-C lamps
- Safe to use 24/7 in the presence of people
- · Built with safety/tamper resistant fasteners to reduce any risk of UV exposure
- · Built-in viewport for visual indication of UV disinfection
- · Quiet operation at 44 dB
- 660 sq ft coverage area*
- · Proven 99.976% reduction of aerosolized SARS-CoV-2 in a single pass
- 2 x 95W mercury vapor lamps
- 120-277V ballast
- Includes 3-prong 120V plug for easy use
- On/off switch
- IP20 rating

Dimensions LxWxH (in)	Air Flow (CFM)	Air Flow (CFH)	Power (W)	Floor Area Coverage (ft²)*	Optimal Mounting Height (ft)	Unit Weight (Ibs)	Mobile Base Weight (Ibs)	
41 x 13 x 6	88	5,280	220	660	6	25	25	




*Coverage area based on 8ft ceiling height





PURDAIR

TECHNICAL DRAWINGS



INSTALLATION

These devices (except for the models with support) should be installed on the wall, at the center of the room, about 6 feet above ground level (avoid positioning at corners; the air captured and treated by the device must be allowed to circulate through the room unhindered). Final disinfection result is related to a higher or lower value of germs in the air during the UV disinfection process. To install the device on the wall use the two triangular brackets enclosed in the packaging. Screw the brackets to the threaded holes on the back side of the device by use of bolts (M6x10) enclosed in the packaging. Make 2 holes on the wall by checking the center distance between the brackets. Secure the device to the wall by means of two expanding wall plugs (8 - 10 mm) (not provided).

HOW TO ORDER

Please specify components below using the letter code in bold to select the desired options.

Model	Lamp Configuration	Lamp Туре	Mounting	Controls	
AU = Aurora Air Fan	2L = with 2 UV-C lamps	95 = 95W mercury vapor UV-C lamp	S = Surface mount M = Mobile cart	MC = Manual control	
Example order: AU-2L-95-S-MC					

